



Pas Reform SmartTouch™ User Interface

For total control over every function and setpoint while
optimizing hatchery connectivity



Pas Reform
Hatchery Technologies



SmartTouch™

Benefits

Simple to operate, ergonomically designed multi-language user interface delivers total control over every function and setpoint. Large, high-contrast, 10.4 inch colour LCD screens with Projective Capacitive Touch screen technology (PCT) and ergonomic user interface viewing angle, allow SmartTouch™ to be configured quickly and simply to programme incubation conditions that meet breed-specific requirements. Connected to SmartCenterPro™, SmartTouch™ also allows for data connection and information exchange to optimise hatchery performance. Includes cleaning mode, to prevent undesired actions during the cleaning of equipment. Durable, high protection rating touch screen is easy to clean.

How it works

- SmartTouch™ delivers total control over every function and setting within each individual incubator, from humidity and CO₂ levels and the position of air inlet valves, to the individual operating parameters – temperature, heating, cooling, ventilation and turning – required per batch/egg type
- SmartTouch™ multi-language user interface design makes operation simple and easily accessible to operators of all skill levels, from experienced hatchery managers to fully automated hatcheries
- SmartTouch™ is interchangeable between the Pas Reform equipment, making the storage of multiple touch screens for each solution unnecessary. Simply position SmartTouch™ in the setter, hatcher or counter and set to the correct operation mode for its setting.

Delivers total control over every function and setting within each individual incubator

Related products

- SmartSetPro™
- SmartHatchPro™
- SmartCount™
- SmartGo™ performance testing tool



Technical Specifications

Display	> 10.4" High contrast colour LCD screen with Projective Capacitive Touch (PCT)
Dimensions	> 530 x 270 x 100 mm
Weight	> 6.7 Kg



Pas Reform
Hatchery Technologies

P.O. Box 2
7038 ZG Zeddam
The Netherlands

Phone +31 314 659 111
Fax +31 314 652 575
info@pasreform.com
www.pasreform.com